

[www.bekindyou.com](http://www.bekindyou.com)

For any questions, please feel free to email us at:


✉ [support@bekindyou.com](mailto:support@bekindyou.com)

**BeKind**  
**ANION**  
**USER MANUAL**

## User Quick Guide

1

**Power on:** Plug in and single press the AnionScroll™ to power on, you will see the real-time temperature (rising up) on LED monitor.




2

**Temperature setting:** Scroll up or down (Increase or decrease temperature) to the exact temperature (265°F-450°F) you want and wait for 3 seconds without pressing or scrolling, and the temperature will be auto-locked while showing "LOC" on monitor (you will see the real-time temperature rising up or falling down to the temperature you set).

Here are the ideal temperature suggestions:  
400-430°F: For course or resistant hair  
375-395°F: For medium or wavy hair  
265-370°F: For fine or fragile hair

**Unlock temperature:** Single press the AnionScroll™ to unlock. Whenever you need to change temperature, please make sure it's unlocked without showing "LOC" on monitor.



3

**Style your hair:** Use BeKind Anion to brush your hair, this will make your hair ready for better styling.

Hold one tangle of hair, operate brush from tip to root of the hair. Follow the same steps for all your hair styling needs with this brush iron.

**Note:** AVOID heating the same group of hair for more than 9 seconds; otherwise, your hair might get damaged.



## Wanna Explore Free Tutorials on How to Style Your Hair Attractive in the Best Way?

Visit our YouTube Channel


→ <https://bit.ly/bekindhair>

Or use the phone camera to scan this QR code



4


**Power off:** Long press (2 seconds at least) the AnionScroll™ to power off whether it is locked or unlocked. Don't forget to unplug it from the socket.



## Product Introduction

Wanna give the best style and touch-up to your hair? BeKind Anion is what you need. With a unique design, great feature and function, this product can help you get your hair styled very attractively in minutes with zero hassle.

## Parts Names



HIGH TEMPERATURE PART



**ATTENTION TO HIGH TEMPERATURE**

Please DON'T touch the heating part by fingers to avoid accidental harm!


## Specification

Model:	BH001	Heater:	MCH
Rate voltage:	100-240V	Working temperature:	450°F
Rate frequency:	50-60Hz	Working indicator light:	LED Digital
Rate power:	43W	Hot parts:	L70*W20*H1.3mm

※ Universal voltage

Made in China

## Thermal Comb Design



Distance between combs and heating

The product is entirely safe. The heating element and comb part are separated. The comb handle remains cool throughout the operation. You won't be hurt when using it.

## Safety Notes And Warnings

Please read the instructions carefully before using the product and also keep this for future references.

### ⚠ DANGEROUS

Please keep the product away from the water. Avoid using this product anywhere near water (bathtub, water containers, washing machines, etc.).



### ⚠ WARNING

- Please pay attention to the product hardware, body, power cord, and plug every time you use it and ensure that it's neither broken nor loose.
- Don't use it if you find any part or component of the product broken or damaged.
- In case, if you find a product is damaged in any aspect, stop using it and please send it for repair to any of your nearest repair shops.
- Product is not recommended for kids, people with health issues or mental illness, and those with the lack of knowledge of using electric appliances or devices.
- Proper handling and attention to operational instruction is the must for using this product and ensuring safety.
- Keep it hidden or away from kids.
- Ensure the power cord does not come in contact with or near the heat ejecting part of the product during and after the use.
- Place or store the product on a heat resistive surface after use. Also, make sure to not bring flammable items like towels or clothes in contact with it. Remember to unplug or disconnect the power cord from the electric/power source when not in use.



### ⚠ NOTES

- The product is designed to be used only for dry hair. Please don't use it for wet hair or on wig hair.
- Avoid wrapping the power cord around the product.
- Make sure the product is cool after using it before you store or place it.
- To avoid hair damage issues during the next use, remember to clean the product after it gets cold after previous uses.
- Don't experiment or use this product for any other purposes than what it's designed for.
- The product will auto-shut-off after one hour without operation to ensure safety.

## How To Use Or Operate?

### Before you operate

- Make sure your hair is completely dry.
- This product gives the best result when operated on washed dry hair.
- Wash and dry your hair before using this brush for smooth, tangle-free, and amazing results.

### ⚠ NOTE

- Don't keep the product plugged to the power source when not in use.
- When in use, place the product only on the heat-resistant surface.
- Make sure you use the product as instructed.
- Keep an eye on the heat/temperature, or it might damage your hair.

### TIPS

Take two clam pins and use one for outer hair first. Then curl the inner hair and vice versa. This will make the process more convenient for you.



## Environment Protection

- Don't dispose of the product carelessly anywhere.
- Dispose of the product only in a recyclable container or at the center.
- Let's together make our environment healthy and safe.

## Cleaning And Storage

- Make sure power is disconnected after every use.
- Allow the product to cool down before you store it safe.
- Used amp cloth to wipe or clean the product.
- Avoid wrapping the power cord around the product.
- Keep the product out of reach from kids.

## Troubleshooting

If you face any performance or operational issue, you should contact the customer support service or get your product repaired from your nearest repair shop.

## If Product Not Working At All.

Check the power source and make sure all your products, connected to the same source, are working.

Check the power cord and ensure it's not damaged. If it is damaged, don't use the product before you get it repaired or it could be dangerous.

## FCC STATEMENT

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television, reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

